General Owner's Information

Vehicle Identification Number (VIN):		
Owner Name:		
Address:		
Phone:		

Your satisfaction is our #1 goal. If you have questions or concerns about your vehicle, we suggest you follow these steps:

- Contact your Sales Representative or Service Advisor at your selling/servicing dealership.
- If the inquiry or concern remains unresolved, contact the Sales Manager or Service Manager at the dealership.
- If the inquiry or concern cannot be resolved at the dealership level, please contact the Ford Customer Assistance
 Center

In the US, contact:

Ford Motor Company Customer Assistance Center 16800 Executive Plaza Drive P.O. Box 6248 Dearborn, Michigan 48126 1-800-392-3673 (FORD) TDD for the hearing impaired: 1-800-232-5952

In Canada, contact:

Customer Assistance Center Ford Motor Company of Canada, Limited

P.O. Box 2000 Oakville, Ontario L6J 5E4 1-800-565-3673 (FORD)

Outside the US or Canada, contact:

Ford Motor Company Worldwide Direct Market Operations 1555 Fairlane Drive Allen Park, Michigan 48101 U.S.A.

Allen Park, Michigan 48101 U.S.A. Telephone: (313) 594-4857 Fax: (313) 390-0804

Find Your Way

Table of Contents

General Maintenance Information
Owner Checks and Services
Normal Schedule
Mileage Intervals 10
Exceptions 33
Special Operating Conditions 34
Maintenance and Service Record 30

Find Your Way

All rights reserved. Reproduction by any means, electronic or mechanical including photocopying, recording or by any information storage and retrieval system or translation in whole or part is not permitted without written authorization from Ford Motor Company.

Copyright © 1998 Ford Motor Company

Find Your Way

Symbol Key

	Cars and Minivans
	Light Trucks, Sport Utilities and Vans
	4x4 Vehicles
Diesel	Diesel
	Natural Gas Vehicles (NGV)
7	Towing a trailer or using a camper or car-top carrier
V	Extensive idling and/or low-speed driving for long distances as in heavy commercial use such as delivery, taxi or patrol car
V	Operating in dusty conditions such as unpaved or dusty roads
<u> </u>	Off-road operation

General Maintenance Information

Why Maintain Your Car?

This guide describes the scheduled maintenance required for your vehicle. Carefully following this schedule helps protect against major repair expenses resulting from neglect or inadequate maintenance and may also help to increase the value of your vehicle when you sell or trade it.

It is your responsibility to see that all scheduled maintenance is performed and that the materials used meet Ford engineering specifications. Failure to perform scheduled maintenance specific in this guide will invalidate warranty coverage on parts affected by the lack of maintenance. Be sure receipts for completed maintenance are kept with the vehicle and confirmation of the work performed is always recorded in this guide.

Your Ford or Lincoln Mercury dealer, or Ford or Lincoln Mercury Auto Care service center has factory trained technicians who can perform the required maintenance using genuine Ford parts. They are committed to meeting your service needs and to assuring your continuing satisfaction.

Protecting Your Investment

Maintenance is an investment that will pay dividends in the form of improved reliability, durability and resale value. To assure the proper performance of your vehicle and its emission control systems, it is imperative that scheduled maintenance be completed at the designated intervals.

Ford strongly recommends the use of genuine Ford replacement parts. Parts other than Ford, Motorcraft or Ford authorized remanufactured parts that are used for maintenance replacement or for the service of components affecting emission control must be equivalent to genuine Ford Motor Company parts in performance and durability. It is the owner's responsibility to determine the equivalency of such parts. Please consult your Warranty Guide for complete warranty information.

General Maintenance Information

No Cost PCV Valve Replacement

The PCV valve is a critical emission component. For all vehicles equipped with 4 cylinder engines, your dealer will replace the PCV valve free of charge at 60,000 miles except in California and Canada. For all light truck vehicles equipped with V6, V8, or V10 engines, your dealer will replace the PCV valve free of charge at 100,000 miles except in California and Canada.

For all passenger vehicles with V-6 or V-8 engines, it is not necessary to replace the PCV valve until 100,000 miles. This replacement will be at the vehicle owner's expense. If you are unsure about your engine type, ask your dealer.

Which Maintenance Schedule Should You Follow?

Normal Schedule

The Normal Schedule applies to those who operate their vehicle under typical, everyday driving conditions. This maintenance frequency represented in this schedule typifies what the vast majority of vehicle operators will require. The listed services should be performed at specified mileage intervals. In addition, there are several exceptions to this Normal Schedule for specific vehicles or special applications. These are listed following the Normal Schedule mileage intervals. If you have any questions about your driving conditions, or for further clarification, please see your dealer.

General Maintenance Information

Special Operating Conditions

If you operate your Ford/Lincoln/Mercury **primarily** in any of the more demanding "**Special Operating Conditions**" listed below, you will need to have the following items maintained more frequently. If you only **occasionally** operate your vehicle under these conditions, it is not necessary to perform the additional maintenance. For specific recommendations see your dealership service advisor or qualified service professional.

- Towing or carrying heavy loads
- Extensive idling and/or driving at low-speeds for long distances
- Driving in dusty conditions
- Off-road operation

Owner Checks and Services

Refer to Mileage Intervals for Additional Checks and Services

Certain basic maintenance checks and inspections should be performed by the owner or a service technician at the intervals indicated. Service information and supporting specifications are provided in the Owner's Guide.

Any adverse condition should be brought to the attention of your dealer or qualified service technician as soon as possible for the proper service advice. The owner maintenance service checks are generally not covered by warranties so you may be charged for labor, parts or lubricants used.



Check Every Month for All Vehicles:

\bigcirc	Check function of all interior and exterior lights
\bigcirc	Check tires for wear and proper air pressure
\bigcirc	Check engine oil fluid level
\bigcirc	Check windshield washer solvent fluid level
\bigcirc	Check and drain fuel/water separator (diesel vehicles)

Owner Checks and Services

/	Check Every Six Months for All Vehicles:
	Check lap/shoulder belts and seat latches for wear and function
	Check air pressure in spare tire
	Check power steering fluid level
	Check washer spray, wiper operation, and clean all wiper blades
	Check parking brake for proper operation
	Check and lubricate all hinges, latches and outside locks
	Check and lubricate door rubber weatherstrips
	Check and clean body and door drain holes
	Check safety warning lamps (brake, ABS, air bag, safety belt) for operation
	Check cooling system fluid level and coolant strength
	Check battery water level (non-maintenance free)
	Check battery connections and clean if necessary
	Check clutch fluid level, if equipped

The following section contains the "Normal Schedule." This schedule is presented at specific mileage intervals with exceptions noted. In addition, those items listed in italic type are additional services that only the noted vehicles require.

Additional Information Available on the Web

To learn more about the importance of routine and dealer-performed maintenance on your vehicle, please visit the Ford Customer Service website. You'll also find important warranty information, customer assistance, technical expertise, frequently asked question and much more. The website location is at: www.ford.com/customerservice/

5,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

10,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles


Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

15,000 miles

Replace fuel filter



^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

20,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

25,000 miles



Cars Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

30,000 miles



Cars and Minivans

	Change engine oil and replace oil filter Inspect automatic transmission fluid level Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and		
0000000000			
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	•	Light Trucks, Sport Utilities, and Vans: All Services Above Plus	
0000	Inspect and lubricate A Replace fuel filter - ga	neel bearings for end play (except F-450/F-550) 4x2 ball joints (except F-450/F-550) asoline engines (E/F Super Duty)* nsmission fluid (Class A Motorhome)	
		4x4: All Services Above Plus	

Lubricate front half-shaft slip yoke

Lubricate transfer case shift linkage, if equipped

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required Replace fuel filter



Natural Gas Vehicles: All Applicable Services Above Plus:

Inspect NGV tanks

35,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

40,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

45,000 miles



Cars and Minivans

	Change engine oil and replace oil filter
\sim	3 3 1
\bigcirc	Inspect automatic transmission fluid level
\bigcirc	Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking
	brake system
\bigcirc	Inspect engine cooling system and hoses
\bigcirc	Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
\bigcirc	Inspect tires for wear and rotate
\bigcirc	Replace cabin air filter, if equipped
	Replace green engine contant if equipped



Light Trucks, Sport Utilities, and Vans: All Services Above Plus

Inspect and lubricate 4x2 ball joints (except F-450/F-550)
Replace fuel filter - gasoline engines (E/F Super Duty)*



4x4: All Services Above Plus

Lubricate transfer case shift linkage, if equipped



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required
Replace fuel filter

50,000 miles



Cars Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

55,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)

Diesel

Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

60,000 miles



Cars and Minivans

Change engine oil and replace oil filter
Inspect automatic transmission fluid level
Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and
parking brake system
Inspect engine cooling system and hoses
Inspect exhaust system and heat shields
Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
Inspect tires for wear and rotate
Replace engine air filter
Replace fuel filter*
Replace cabin air filter, if equipped

^{*}if vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

		Normai Schedule
0000	Perform automatic tra	•
	ř	Light Trucks, Sport Utilities, and Vans: All Services Above Plus
000000	Inspect/adjust 4x2 wh Lubricate 4x2 wheel I Replace fuel filter - g Replace manual trans	4x2 ball joints (except F-450/F-550) heel bearings for end play (except F-450/F-550) bearings (except F-450/F-550) pasoline engines (E/F Super Duty)* mission fluid nsmission fluid (Class A Motorhome)
		4x4: All Services Above Plus
	Lubricate front half-sh Replace transfer case Lubricate transfer case	
Die	sel	Diesel: All Applicable Services Above Plus
	Check air filter minde Replace fuel filter	er, replace filter as required
		Natural Gas Vehicles: All Applicable Services Above Plus:
	Inspect NGV tanks	

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

65,000 miles



Cars Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

70,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:


Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

75,000 miles

Replace fuel filter



^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

80,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

85,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

90,000 miles



Cars and Minivans

000 0000000000	Change engine oil and replace oil filter Inspect automatic transmission fluid level Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system Inspect engine cooling system and hoses Inspect exhaust system and heat shields Inspect steering linkage, suspension, and if equipped driveshaft and ball joints Inspect tires for wear and rotate Replace engine air filter Replace fuel filter* Replace cabin air filter, if equipped Replace spark plugs (Villager) Inspect drive belt (Villager) Perform automatic transmission/transaxle services on all vehicles equipped with AX4S, AX4N, 4R70W. Consult your dealer for your particular requirements.
(+:4	Light Trucks, Sport Utilities, and Vans: All Services Above Plus
0000	Inspect and lubricate 4x2 ball joints (except F-450/F-550) Inspect/adjust 4x2 wheel bearings for end play (except F-450/F-550) Replace fuel filter - gasoline engines (E/F Super Duty)* Change automatic transmission fluid (Class A Motorhome)
	1

Lubricate front half-shaft slip yoke

Lubricate transfer case shift linkage, if equipped

4x4: All Services Above Plus

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required Replace fuel filter



Natural Gas Vehicles: All Applicable Services Above Plus:

Inspect NGV tanks

95,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

100,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

- Change engine oil and replace oil filter
- Inspect accessory drive belt(s)
- Inspect tires for wear and rotate (Recommended for optimal tire life)
- Replace PCV valve (except for 4 cylinder engines. See page 5.)
 - Replace spark plugs (except Villager)



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

105,000 miles



Cars and Minivans

- Change engine oil and replace oil filter
 - Inspect automatic transmission fluid level
 - Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking
 - brake system
- Inspect engine cooling system and hoses
- Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
- Inspect tires for wear and rotate
- Replace cabin air filter, if equipped
- Replace green engine coolant, if equipped
- Replace camshaft belt (Villager)



Light Trucks, Sport Utilities, and Vans: All Services Above Plus

Inspect and lubricate 4x2 ball joints (except F-450/F-550)
Replace fuel filter - gasoline engines (E/F Super Duty)*



4x4: All Services Above Plus

Lubricate transfer case shift linkage, if equipped



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required
Replace fuel filter

110,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

115,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)

Diesel

Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

120,000 miles



Cars and Minivans

	Change engine oil and replace oil filter Inspect automatic transmission fluid level
\bigcirc	Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and
	parking brake system
\bigcirc	Inspect engine cooling system and hoses
\bigcirc	Inspect exhaust system and heat shields
\bigcirc	Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
\bigcirc	Inspect tires for wear and rotate
\bigcirc	Replace engine air filter
\bigcirc	Replace fuel filter*
	Panlace cahin air filter if equipped

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

0000	Perform automatic tra AX4S, AX4N, 4R70W.	ager) I 4 cylinder engine vehicles) Insmission/transaxle services on all vehicles equipped with Consult your dealer for your particular requirements. In all 2.0L, 4 cylinder engines (Escort, Tracer, Contour,
)	Light Trucks, Sport Utilities, and Vans: All Services Above Plus
0000000	Lubricate 4x2 wheel b Inspect and lubricate 4 Replace fuel filter - ga Change automatic trans	nission fluid neel bearings for end play (except F-450/F-550) nearing (exc
		4x4: All Services Above Plus
000	Lubricate front half-sh Replace transfer case Lubricate transfer case	
Die	sel	Diesel: All Applicable Services Above Plus
	Check air filter minder Replace fuel filter	r, replace filter as required
		Natural Gas Vehicles: All Applicable Services Above Plus:
	Drain coalescent fuel f Inspect NGV tanks	filter bowl

125,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)

Diesel

Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

130,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

135,000 miles



Cars and Minivans

Change engine oil and replace oil filter
Inspect automatic transmission fluid level
Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system
Inspect engine cooling system and hoses
Inspect steering linkage, suspension, and if equipped driveshaft and ball joints
Inspect tires for wear and rotate
Replace cabin air filter, if equipped
Replace green engine coolant, if equipped



Light Trucks, Sport Utilities, and Vans: All Services Above Plus

Inspect and lubricate 4x2 ball joints (except F-450/F-550)

Replace fuel filter - gasoline engines (E/F Super Duty)*



4x4: All Services Above Plus

Lubricate transfer case shift linkage, if equipped



Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required Replace fuel filter

140,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)

Diesel

Diesel: All Applicable Services Above Plus

Check air filter minder, replace filter as required

145,000 miles



Cars, Minivans, Light Trucks, Sport Utilities, Vans, 4x4 and Natural Gas Vehicles:

Change engine oil and replace oil filter
Inspect tires for wear and rotate (Recommended for optimal tire life)



Diesel: All Applicable Services Above Plus

150,000 miles



Cars and Minivans

000000000000000000000000000000000000000	Change engine oil and replace oil filter Inspect automatic transmission fluid level Inspect brake pads/shoes/rotors/drums, brake lines & hoses, and parking brake system Inspect engine cooling system and hoses Inspect exhaust system and heat shields Inspect steering linkage, suspension, and if equipped driveshaft and ball joints Inspect tires for wear and rotate Replace engine air filter Replace fuel filter* Replace cabin air filter, if equipped Replace orange engine coolant, if equipped Replace spark plugs (Villager) Inspect drive belt (Villager) Perform automatic transmission/transaxle services on all vehicles equipped with AX4S, AX4N, 4R70W. Consult your dealer for your particular requirements.	
	•	Light Trucks, Sport Utilities, and Vans: All Services Above Plus
0000	Inspect and lubricate 4x2 ball joints (except F-450/F-550) Inspect/adjust 4x2 wheel bearings for end play (except F-450/F-550) Replace fuel filter - gasoline engines (E/F Super Duty)* Change automatic transmission fluid (Class A Motorhome)	
		4x4: All Services Above Plus
	Lubricate front half-shaft slip yoke Lubricate transfer case shift linkage, if equipped	

^{*}If vehicle is registered in California, the California Air Resources Board has determined that the failure to perform this maintenance item will not nullify the emission warranty or limit recall liability prior to the completion of the vehicle's useful life. We, however, urge that all recommended maintenance services be performed at the indicated intervals and the maintenance be recorded.

Diesel		Diesel: All Applicable Services Above Plus
	Check air filter minder, replace filter as required Replace fuel filter	
		Natural Gas Vehicles: All Applicable Services Above Plus:
	Inspect NGV tanks	
Ex	ceptions	
	Natural Gas Vehicles	3
	Every 15 years - Replace NGV tank(s)	
	Class A Motorhome	
	Every two years - Cha	inge brake fluid

Normal Vehicle Axle Maintenance

Rear axles containing synthetic lubricant and light duty trucks equipped with Ford-design axles are lubricated for life. These lubricants are not to be checked or changed unless a leak is suspected, service is required or the axle assembly has been submerged in water. The axle lubricant should be changed anytime the axle has been submerged in water.

Non-synthetic rear axle lubricants should be replaced ever 3,000 miles or 3 months, whichever occurs first, during extended trailer tow operation above 21 Celsius (70 degrees Fahrenheit) ambient and wide open throttle for extended periods above 45 mph. The 3,000 mile lube change interval may be waived if the axle was filled with 75W140 synthetic gear lubricant meeting Ford specification WSL-M2C192-A, part number F1TZ-19580-B or equivalent. Add four ounces of additive friction modifier C8AZ-19B546-A (EST-M2C118-A) or equivalent for complete refill of Traction-Lok rear axles. The rear axle lubricant should be changed anytime the axle has been submerged in water.

Police and Taxi Vehicle Axle Maintenance

Replace rear axle lubricant every 160,000 km (100,000 miles). Rear axle lubricant change may be waived if the axle was filled with 75W140 synthetic gear lubricant meeting Ford specification WSL-M2C192-A, part number FITZ-19580-B or equivalent. Add four ounces of additive friction modifier C8AZ-19B546-A (EST-M2C118-A) or equivalent for complete refill of Traction-Lok rear axles. The rear axle lubricant should be changed anytime the axle has been submerged in water.

Special Operating Conditions

Items Needing Special Attention

If you operate your Ford/Lincoln/Mercury **primarily** in any of the more demanding "Special Operating Conditions" listed below, you will need to have the following items maintained more frequently. If you only occasionally operate your vehicle under these conditions it is not necessary to perform the additional maintenance. For specific recommendations see your dealership service advisor or qualified service professional.



Towing a trailer or using a camper or car-top carrier

Every 3,000 miles or 3 months Replace engine oil and filter

Every 30,000 miles Change automatic transmission fluid

As required Change manual transmission fluid
As required Inspect and lubricate U-joints



Extensive idling and/or low-speed driving for long distances as in heavy commercial use such as delivery, taxi or patrol car

Every 3,000 miles or 3 months Replace engine oil and filter

Every 5,000 miles Inspect brake system
Every 15,000 miles Replace fuel filter

Every 30,000 miles Change automatic transmission fluid

Every 60,000 miles Replace spark plugs
As required Replace cabin air filter

Special Operating Conditions



Operating in dusty conditions such as unpaved or dusty roads

Every 3,000 miles or 3 months

Replace engine oil and filter

Every 15,000 miles Every 30,000 miles

Replace fuel filter

As required

Change automatic transmission fluid

As required Replace engine air filter **As required** Replace cabin air filter



Off-road operation

Every 30,000 miles

Change automatic transmission fluid

As required

Replace cabin air-filter

As required

Inspect and lubricate U-joints

See An Authorized Dealer

This section of the guide is designed to allow your Ford or Lincoln Mercury dealer, or Ford or Lincoln Mercury Auto Care service center or other qualified service technician to record that the recommended service was completed at the appropriate mileage intervals. Be sure to ask your service provider to record each time service is performed.

Date:	Dealer's Stamp:	
Mileage:		
See correspondin	g mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:	
Mileage:		
See corresponding mileage in maintenance schedule for services performed.		
Date:	Dealer's Stamp:	
Mileage:		

Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	

Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
·	,
Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
·	
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	
Coo correspondir	ng mileage in maintenance schedule for services performed

Date:	Dealer's Stamp:
Mileage:	
See corresponding	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See corresponding	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	
•	

Date:	Dealer's Stamp:		
Mileage:			
See correspondin	g mileage in maintenance schedule for services performed.		
Date:	Dealer's Stamp:		
Mileage:			
See corresponding	See corresponding mileage in maintenance schedule for services performed.		
Date:	Dealer's Stamp:		
Mileage:			
See corresponding mileage in maintenance schedule for services performed.			
Date:	Dealer's Stamp:		
Mileage:			
-			
Con correspondin	a milagae in maintangnee schedule for sarvices norformed		

Date:	Dealer's Stamp:
Mileage:	
See correspondir	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondir	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondir	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	

Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
·	,
Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
·	
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	
Coo correspondir	ng mileage in maintenance schedule for services performed

Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	

Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
·	,
Date:	Dealer's Stamp:
Mileage:	
See correspondir	g mileage in maintenance schedule for services performed.
·	
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	
Coo correspondir	ng mileage in maintenance schedule for services performed

Date:	Dealer's Stamp:
Mileage:	
See correspondir	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondir	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondir	ng mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	

Date:	Dealer's Stamp:
Mileage:	
See correspondin	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondin	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See corresponding mileage in maintenance schedule for services performed.	
Date:	Dealer's Stamp:
Mileage:	
See corresponding	g mileage in maintenance schedule for services performed.

Date:	Dealer's Stamp:
Mileage:	
See correspondin	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondin	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	
See correspondin	g mileage in maintenance schedule for services performed.
Date:	Dealer's Stamp:
Mileage:	